

Solutions for Your TOUGHEST
MIXING Applications in

FOOD

Introduction

The Process

The Problem

The Solution

The Advantages

Ice Cream Manufacture -
Hydration of Stabilizers
and Emulsifiers



Ice Cream Manufacture - Hydration of Stabilizers and Emulsifiers

Stabilizers and Emulsifiers make up only a small proportion of an ice cream mix (typically no more than 1%) but contribute a number of properties to the product:

- Freeze-thaw stability. When dispersed into the liquid phase, stabilizers hydrate, binding water into a network of small droplets. The restriction in flow of “free” water in the mix prevents large ice crystals from forming during freezing.
- The thickening or gelling effect also contributes to “body” and texture (or “mouthfeel”).
- In low fat products, stabilizers act as gelling and bulking agents, replacing the body and texture normally provided by the fat content.
- Emulsifiers are added to ensure the fat content of an ice cream mix is finely dispersed to prevent the product taking on a “buttery” texture.

There are many stabilizers and emulsifiers available, (see list) and it is common to use a blend of stabilizers to obtain the optimum product characteristics. Combined stabilizer/emulsifier products are also available.

Stabilizers:

- Protein type: Gelatin, Egg white
- Gums: Guar gum, locust bean gum, xanthan gum
- Seaweed extracts: Sodium alginate, propylene glycol alginate (PGA) Carrageenan
- Cellulose Based: CMC, microcrystalline cellulose (MCC)

Emulsifiers:

- Mono-diglycerides
- Polyglycerol esters
- Sorbitan esters

The Process

Preparation of a typical ice cream mix is described in a separate report. In order to successfully disperse and hydrate the stabilizers and emulsifiers, the following process requirements must be met:

- The powder/liquid blending system must be capable of rapidly incorporating the powder, and dispersing it throughout the contents of the mix.
- Stabilizers/emulsifiers tend to agglomerate when added to the base liquid. The mixer must be capable of breaking these down.
- The stabilizer/emulsifier must also be reduced to the smallest possible particle size to maximize yield. Some products are not “activated” unless particle size is sufficiently reduced.
- Similarly, a degree of shear is sometimes required to activate some products and fully hydrate them.


The Problem

A number of problems can be encountered when using conventional powder/liquid blending systems and agitators:

- Powder must be added at a controlled rate to reduce agglomeration of particles.
- Premixing of powders, often carried out to reduce agglomeration, increases costs and process time.
- Conventional systems do not produce sufficient shear to break agglomerates down.
- Long processing times are required to complete dispersion and achieve a satisfactory consistency.
- Poor dispersion can lead to clusters of partially hydrated material building up on the walls of the heat exchanger, impairing heat transfer.
- Agglomerates can also adversely affect homogenizer performance, leading to inconsistent results.
- Frequent cleaning cycles are required, resulting in increased costs from down time, cleaning chemicals and waste of expensive raw materials.
- Incomplete hydration also reduces yield of raw materials.
- Many formulations contain unnecessarily high levels of these raw materials to compensate for poor yield and wastage.


The Solution

The above problems can be overcome by adding a Silverson High Shear In-Line mixer to the existing process. Operation is described below. Typically this is installed at the discharge of the powder/liquid blending equipment, often in place of a centrifugal pump.




Stage 1

The high speed rotation of the rotor blades creates a powerful suction which draws the liquid and solid/powdered ingredients into the workhead. These can be added without the need for pre-mixing.



Stage 2

The materials are subjected to intense shear in the confined area of the workhead. Agglomerates are broken down in the gap between the rotor blades and stator wall. A lump-free mixture is rapidly obtained.



Stage 3

The product is forced out of the stator as fresh material is drawn into the workhead. A circulatory mixing cycle develops in which all the material passes through the Silverson workhead, accelerating the hydration process.

FOOD


The Advantages

- Premixing of powdered ingredients is not necessary
- Agglomerate-free mix
- Rapid Mixing times
- Longer run between cleaning cycles
- Maximized yield of raw materials as thickening agents are fully hydrated and other ingredients are fully dispersed
- Greater uniformity between batches

The batch size, formulation, type of ingredients and the viscosity of the mix dictates which machine from the Silverson product line is suited to individual processing requirements.


High Shear In-Line Mixers

- Easily retro fitted to existing plant
- Must be used in conjunction with an efficient in-tank agitator to wet out powder
- Aeration free
- Self pumping
- Can be used to discharge vessel
- Ultra Hygienic models available



Silverson Flashblend

- Ideal for larger batches
- Capable of rapidly incorporating large volumes of powders
- Minimized aeration
- Minimized cleaning requirements
- Controlled powder addition rate
- Minimum operator input required



Silverson Machines, Inc. 355 Chestnut Street, East Longmeadow, MA 01028
Ph: (413) 525-4825 • Fax: (413) 525-5804 • www.silverson.com

Issue No. 27FA2

Information contained in this report is believed to be correct and is included as a guide only. No warranty is expressed or implied as to fitness for use or freedom from patents. Silverson Machines reserve the right to change product specification without notice.